

Tap MENU on the interface while looking at the main menu to reveal the APPLICATION menu.




There are four useful features in this menu:

**DELETE** – removes any application and its data from your PDA; use this carefully.



**BEAM** allows you to transmit a program in your PDA to another user's PDA.

**CATEGORY** allows you to sort applications into main menu groups for easier organization.



**INFO** displays the PDA's memory and other function allocations.

