

Tap PREFS from main menu to reveal this screen.

Set the time, date, and other personal preferences as desired.

Note that is “BEAM RECEIVE” is on, your Palm will be in “automatic reception” mode for anyone who tries to beam you a record or program item.

Tap the down arrow in the upper right corner to reveal a menu of other preference areas.

Two of the most common prefs to be adjusted are OWNER and BUTTON

